

Neosys Technology Inc.

Nuvo-3616VR/3608VR Series

***Intel® 3rd-Gen Core™ i7/i5 Fanless Surveillance
System with 16x/8x 802.3at PoE+ & 4x HDD RAID***

User's Manual

Rev. A1

Published March 31th, 2015



Revision History

Date	Change List	Version
2015/3/31	First formal release	A1



Contents

Disclaimer.....	6
Declaration of Conformity	6
FCC	6
CE.....	6
Copyright and Trademarks	6
Chapter 1 Introduction	7
1.1 Overview.....	7
1.2 Product Specification	8
1.2.1 Specification of Nuvo-3616VR	8
1.2.2 Specification of Nuvo-3608VR	9
1.3 Supported CPU List.....	11
Chapter 2 Getting to know your Nuvo-3616VR.....	12
2.1 Unpacking your Nuvo-3616VR Series	12
2.2 Front Panel I/O Functions.....	13
2.2.1 Power Button	13
2.2.2 Reset Button	14
2.2.3 LED Indicators	14
2.2.4 CFAST Socket	15
2.2.5 PS/2 Keyboard and Mouse Connectors	15
2.2.6 Gigabit Ethernet Port.....	16
2.2.7 VGA Connector	17
2.2.8 Remote On/Off Control and Status LED Output.....	17
2.2.9 USB 3.0 Connectors	19
2.2.10 DVI/HDMI Connectors.....	19
2.2.11 USB 2.0 Connectors.....	20
2.2.12 Speaker-out and MIC-in Audio Jacks	21
2.3 Back Panel I/O Functions	22
2.3.1 3-Pin Terminal Block for DC Input	22
2.3.2 COM Ports (COM1 & COM2)	23
2.3.3 Gigabit Ethernet PoE+ Ports	24
2.4 Internal I/O Functions	26
2.4.1 DDR3 SODIMM Sockets	26
2.4.2 SATA Ports for Internal HDD	27
2.4.3 SATA Ports for Easy-Swap HDD Trays	28
2.4.4 Mini PCI Express Connector#1 (with SIM Socket)	29
2.4.5 Mini PCI Express Connector#2	30
2.5 Mechanical Dimension.....	31
2.5.1 Top View of Nuvo-3616VR series.....	31



2.5.2 Front View of Nuvo-3616VR series	32
2.5.3 Side View of Nuvo-3616VR series	32
2.5.4 Bottom View of Nuvo-3616VR series	33
Chapter 3 Getting Start	34
3.1 Disassemble your Nuvo-3616VR series	34
3.2 Install DDR3 SODIMM Modules	35
3.3 Install 2.5" HDD/SSD on Internal SATA Ports	36
3.4 Install 2.5" HDD/SSD on Easy-Swap Trays	37
3.5 Mount your Nuvo-3616VR	40
3.6 Connect DC Power to you Nuvo-3616VR.....	43
3.7 Power on your Nuvo-3616VR series.....	45
3.7.1 Power on Nuvo-3616VR Using the Power Button.....	45
3.7.2 Power on Nuvo-3616VR Using an External Non-latched Switch	45
3.7.3 Power on Nuvo-3616VR Using Wake-on-LAN Function	46
3.8 Ignition Power Control	50
3.8.1 Principle of Ignition Power Control	50
3.8.2 Wiring Ignition Signal	52
3.8.3 Operation Modes of Ignition Power Control	53
Chapter 4 BIOS and Driver	57
4.1 BIOS Settings	57
4.1.1 COM1 & COM2 Operating Mode	57
4.1.2 SATA Controller Mode.....	58
4.1.3 Power On after Power Failure Option	59
4.1.4 W_DISABLE# for Mini-PCIe Sockets	59
4.1.5 Wake-on-LAN Option	60
4.1.6 Watchdog Timer for Booting.....	61
4.1.7 Select a Boot Device.....	62
4.1.8 Position New Boot Device.....	63
4.2 Configure AMT	64
4.3 Configure RAID Function.....	65
4.4 Operating System Support.....	66
4.5 Driver Installation	67
4.5.1 Install All Drivers Using "One-Click" Driver Installation.....	67
4.5.2 Install Drivers Manually	68
4.5.3 Install Driver for WDT and Per-port PoE On/Off Control	70
Appendix A Using Watchdog Timer	71
Install WDT_DIO Library	71
WDT Function Reference	73
Appendix B Using Per-Port PoE On/Off Control	76
Per-Port PoE On/Off Control Function Reference	76





Disclaimer

This manual is intended to be used as a practical and informative guide only and is subject to change without prior notice. It does not represent commitment from Neousys Technology Inc. Neousys shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of the product or documentation, nor for any infringements upon the rights of third parties, which may result from such use.

Declaration of Conformity

FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

Copyright and Trademarks

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Company/product names mentioned herein are used for identification purposes only and are trademarks and/or registered trademarks of their respective companies.



Chapter 1 Introduction

1.1 Overview

Nuvo-3616VR series is world's first surveillance platform integrates 16 PoE+ ports, i7 CPU and RAID in a compact, fanless chassis. It is designed to meet requirements of a stationary or mobile surveillance system, and is capable for not only video recording but also high-end video analytics.

A typical surveillance system uses a NVR to connect IP cameras and record video streams on its disk array. Similar to a NVR, Nuvo-3616VR features 16 PoE+ ports and built-in disk array for video recording. Each of its 802.3at PoE+ ports can supply 25.5W to power a bullet, dome or PTZ camera. Nuvo-3616VR also incorporates built-in 4-drives RAID for up to 8TB storage capacity. More than the off-the-shelf NVR, Nuvo-3616VR comes with a quad-core i7 CPU, which delivers extraordinary computing performance to facilitate advanced video analytics algorithms.

Nuvo-3616VR inherits Neousys' proven fanless architecture to ensure true wide-temperature operation. Two of its four 2.5" drives come with Neousys' patent easy-swap trays for simple HDD/SSD replacement. Nuvo-3616VR also features 8~35V wide-range DC input and ignition control for stationary or in-vehicle usage. Combine numerous PoE+ ports, RAID storage and superb computing power, Nuvo-3616VR ignites a new era of surveillance applications!



Nuvo-3616VR



Nuvo-3608VR

1.2 Product Specification

1.2.1 Specification of Nuvo-3616VR

System Core	
Processor	Supports the following CPU <ul style="list-style-type: none"> ● Intel® Core™ i7-3610QE (2.3/3.3 GHz, 6 MB cache) ● Intel® Core™ i5-3610ME (2.7/3.3 GHz, 3 MB cache)
Chipset	Intel® QM77 Platform Controller Hub with AMT & RAID support
Graphics	Integrated Intel® HD Graphics 4000 Controller
Memory	2x 204-pin SO-DIMM sockets, up to 16 GB DDR3 1333/1600 MHz SDRAM
I/O Interface	
PoE	16x IEEE 802.3at (25.5W) PoE+ Ports with per-port power on/off control 160W total power budget
Ethernet	1x Gigabit Ethernet ports by Intel® 82579LM, supporting AMT
Video Port	1x DB-15 connector for analog RGB, supporting 2048x1536 resolution 2x DVI-D connectors for DVI/HDMI outputs, supporting 1920x1200 (DVI/HDMI) resolution
USB	2x USB 3.0 ports and 2x USB 2.0 ports
Serial Port	2x software-programmable RS-232/422/485 (COM1 & COM2)
KB/MS	1x 6-pin mini-DIN connector for PS/2 keyboard/mouse
Audio	1x mic-in and 1x speaker-out
Storage Interface	
SATA HDD	4x Internal SATA port for 2.5" HDD/SSD installation with RAID 0/1/5/10 support
CFast	1x CFast socket
Expansion Bus	
Mini PCI-E	1x internal mini PCI Express socket with USIM socket 1x internal mini PCI Express socket
Power Supply & Ignition Control	
DC Input	1x 3-pin pluggable terminal block for 8~35V DC input (for direct DC wiring)
Maximal Power Consumption	With Core™ i7-3610QE: 81.8W (3.41A@24V) With Core™ i5-3610ME: 62.7W (2.61A@24V)
Ignition Control	Ignition power control with configurable on/off delay (V+/GND/IGN)
Remote Ctrl. & Status Output	1x 10-pin (2x5) wafer connector for remote on/off control and status LED output
Mechanical	



Dimension	240 mm (W) x 255 mm (D) x 70 mm (H)
Weight	5.0 Kg
Mounting	Wall-mounting (Standard)
Environmental	
Operating Temperature	-25°C ~ 60°C */**
Storage Temperature	-40°C ~85°C
Humidity	10%~90% , non-condensing
Vibration	Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
Shock	Operating, 50 Grms, Half-sine 11 ms Duration (w/ SSD, according to IEC60068-2-27)
EMC	CE/FCC Class A, according to EN 55022 & EN 55024

* Maximal power consumption is measured with 16GB DDR3 memory and four 2.5" SATA HDD installed under the following conditions:

1. 100% CPU loading
2. Operating for all GbE ports
3. No PoE device attached

** High-temperature test is executed with 100% CPU loading applied using Passmark® BurnInTest™ v7.0. For detail testing criteria, please contact Neosys Technology

*** For sub-zero operating temperature, a wide temperature HDD drive or Solid State Disk (SSD) is required.

1.2.2 Specification of Nuvo-3608VR

System Core	
Processor	Supports the following CPU <ul style="list-style-type: none"> ● Intel® Core™ i7-3610QE (2.3/3.3 GHz, 6 MB cache) ● Intel® Core™ i5-3610ME (2.7/3.3 GHz, 3 MB cache)
Chipset	Intel® QM77 Platform Controller Hub with AMT & RAID support
Graphics	Integrated Intel® HD Graphics 4000 Controller
Memory	2x 204-pin SO-DIMM sockets, up to 16 GB DDR3 1333/1600 MHz SDRAM
I/O Interface	
PoE	8x IEEE 802.3at (25.5W) PoE+ Ports with per-port power on/off control 80W total power budget
Ethernet	1x Gigabit Ethernet ports by Intel® 82579LM, supporting AMT
Video Port	1x DB-15 connector for analog RGB, supporting 2048x1536 resolution 2x DVI-D connectors for DVI/HDMI outputs, supporting 1920x1200 (DVI/HDMI) resolution
USB	2x USB 3.0 ports and 2x USB 2.0 ports
Serial Port	2x software-programmable RS-232/422/485 (COM1 & COM2)
KB/MS	1x 6-pin mini-DIN connector for PS/2 keyboard/mouse
Audio	1x mic-in and 1x speaker-out



Storage Interface	
SATA HDD	4x Internal SATA port for 2.5" HDD/SSD installation with RAID 0/1/5/10 support
CFast	1x CFast socket
Expansion Bus	
Mini PCI-E	1x internal mini PCI Express socket with USIM socket 1x internal mini PCI Express socket
Power Supply & Ignition Control	
DC Input	1x 3-pin pluggable terminal block for 8~35V DC input (for direct DC wiring)
Maximal Power Consumption	With Core™ i7-3610QE: 74.2W (3.09A@24V) With Core™ i5-3610ME: 55.1W (2.30A@24V)
Ignition Control	Ignition power control with configurable on/off delay (V+/GND/IGN)
Remote Ctrl. & Status Output	1x 10-pin (2x5) wafer connector for remote on/off control and status LED output
Mechanical	
Dimension	240 mm (W) x 255 mm (D) x 70 mm (H)
Weight	5.0 Kg
Mounting	Wall-mounting (Standard)
Environmental	
Operating Temperature	-25°C ~ 60°C **/**
Storage Temperature	-40°C ~85°C
Humidity	10%~90% , non-condensing
Vibration	Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
Shock	Operating, 50 Grms, Half-sine 11 ms Duration (w/ SSD, according to IEC60068-2-27)
EMC	CE/FCC Class A, according to EN 55022 & EN 55024

* Maximal power consumption is measured with 16GB DDR3 memory and four 2.5" SATA HDD installed under the following conditions:

1. 100% CPU package power
2. Operating for all GbE ports
3. No PoE device attached

** High-temperature test is executed with 100% CPU loading applied using Passmark® BurnInTest™ v7.0. For detail testing criteria, please contact Neosys Technology

*** For sub-zero operating temperature, a wide temperature HDD drive or Solid State Disk (SSD) is required.



1.3 Supported CPU List

Nuvo-3616VR series accepts a PGA-type Intel® 3rd-Gen i7/i5 processor via the rPGA988 CPU socket. In addition to i7-3610QE, i5-3610ME, you may also select other processor listed below according to your consideration of cost and performance.

- Intel® Core™ i7-3840QM Processor (8M Cache, up to 3.80 GHz)
- Intel® Core™ i7-3820QM Processor (8M Cache, up to 3.70 GHz)
- Intel® Core™ i7-3740QM Processor (6M Cache, up to 3.70 GHz)
- Intel® Core™ i7-3720QM Processor (6M Cache, up to 3.60 GHz)
- Intel® Core™ i7-3630QM Processor (6M Cache, up to 3.40 GHz)
- Intel® Core™ i7-3612QM Processor (6M Cache, up to 3.10 GHz)
- Intel® Core™ i7-3610QM Processor (6M Cache, up to 3.30 GHz)
- Intel® Core™ i7-3610QM Processor (6M Cache, up to 3.30 GHz)
- **Intel® Core™ i7-3610QE Processor (6M Cache, up to 3.30 GHz) ***
- Intel® Core™ i7-3540M Processor (4M Cache, up to 3.70 GHz)
- Intel® Core™ i7-3520M Processor (4M Cache, up to 3.60 GHz)
- **Intel® Core™ i5-3610ME Processor (3M Cache, up to 3.30 GHz) ***
- Intel® Core™ i5-3380M Processor (3M Cache, up to 3.60 GHz)
- Intel® Core™ i5-3360M Processor (3M Cache, up to 3.50 GHz)
- Intel® Core™ i5-3340M Processor (3M Cache, up to 3.40 GHz)
- Intel® Core™ i5-3320M Processor (3M Cache, up to 3.30 GHz)
- Intel® Core™ i5-3230M Processor (3M Cache, up to 3.20 GHz)
- Intel® Core™ i5-3210M Processor (3M Cache, up to 3.10 GHz)
- **Intel® Core™ i3-3120ME Processor (3M Cache, 2.40 GHz) ***
- Intel® Core™ i3-3120M Processor (3M Cache, 2.50 GHz)
- Intel® Core™ i3-3110M Processor (3M Cache, 2.40 GHz)
- Intel® Celeron® Processor 1020M (2M Cache, 2.10 GHz)
- **Intel® Celeron® Processor 1020E (2M Cache, 2.20 GHz) ***
- Intel® Celeron® Processor 1000M (2M Cache, 1.80 GHz)

*The processors with * are listed in Intel® Embedded Roadmap and with a 7-year life cycle support (2013~2019).*

Chapter 2 Getting to know your Nuvo-3616VR

2.1 Unpacking your Nuvo-3616VR Series

When you receive the package of Nuvo-3616VR series, please check immediately if the package contains all the items listed in the following table. If any item is missing or damaged, please contact your local dealer or Neosys Technology Inc. for further assistance.

Item	Description	Qty
1	Nuvo-3616VR or Nuvo-3608VR fanless surveillance system (According to the configuration you order, CPU/DDR3/HDD may (not) be included. Please verify these items if necessary.)	1
2	Accessory box, which contains <ul style="list-style-type: none"> ● Neosys Drivers & Utilities DVD ● Wall-mounting bracket ● M4 P-Head screws for wall-mounting bracket ● M3 F-Head crew (If HDD not installed) ● M3 Sprint Screw (If CPU not installed) ● Foot pad ● 3-pin pluggable terminal block 	1 2 4 16 5 4 1



2.2 Front Panel I/O Functions

On Nuvo-3616VR series, plenty of I/O functions are provided on the front panel and back panel so you can easily access them. Most common computer I/O functions are placed on the front panel. In this section, we'll illustrate each I/O function on the front panel.

2.2.1 Power Button



The power button is a non-latched switch with LED for ATX mode on/off operation. To turn on the Nuvo-3616VR series, press the power button and then the blue LED will light up. To turn off the Nuvo-3616VR series, you can either issue a shutdown command in OS or just simply press the power button. In case of system halts, you can press and hold the power button for 5 seconds to compulsorily shut down the system. Please note that a 5 seconds interval is kept by the system between two on/off operations (i.e. once turning off the system, you shall wait for 5 seconds to initiate another power-on operation).

2.2.2 Reset Button



The reset button is used to manually reset the system in case of any abnormal condition. To avoid unexpected operation, the reset button is hidden behind the front panel. You need to use a pin-like object to push the reset button.

2.2.3 LED Indicators



There are three LED indicators on the front panel: HDD, WDT and IGN. The descriptions of these three LED are listed in the following table.

Indicator	Color	Description
HDD	Red	Hard drive indicator, flashing when SATA hard drive is active.
WDT	Yellow	Watchdog timer indicator, flashing when watchdog timer is started.
IGN	Green	Ignition signal indicator, lighted-up when IGN is high (12V/24V).

2.2.4 CFast Socket



Nuvo-3616VR series provides a CFast socket on the front panel. CFast is a new interface for portable storage device. It shares a similar form-factor as CompactFlash but leverages Serial ATA interface to offer higher data transfer rate. The CFast socket on Nuvo-3616VR series is a push-push type. You can insert and push a CFast card to the end to install it, and push the installed CFast card again to eject it.

2.2.5 PS/2 Keyboard and Mouse Connectors



Support for legacy PS/2 keyboard and mouse on Nuvo-3616VR series is implemented using industrial-grade ITE8783 Super IO chip (-40 to 85°C). There is one 6-pin Mini-DIN connector on the front panel to provide PS/2 KB/MS signals. You shall need to use a Y-cable to connect PS/2 keyboard and mouse at the same time.

2.2.6 Gigabit Ethernet Port



Nuvo-3616VR series offers one GbE port using Intel® 82579LM Gigabit Ethernet controller. This GbE port locates on the front panel and it support Wake-on-LAN function. It is also capable of operating with Intel® AMT (Active Management Technology) to support advanced features such remote SOL desktop and remote on/off control. Please refer to section 4.2 for information of configuring AMT, and section 4.5 for information of driver installation for Windows XP/7/8. When plugging in the Ethernet cable, you can tell the Ethernet status and speed from the LED indicators on the RJ45 connector as following:

Active/Link LED

LED Color	Status	Description
Yellow	Off	Ethernet port is disconnected
	On	Ethernet port is connected and no data transmission
	Flashing	Ethernet port is connected and data is transmitting/receiving

Speed LED

LED Color	Status	Description
Green or Orange	Off	10 Mbps
	Green	100 Mbps
	Orange	1000 Mbps

2.2.7 VGA Connector




Nuvo-3616VR series has multiple display outputs on its front panel for connecting different displays according to your system configuration. VGA connector is the most popular way for connecting a display. The VGA output of Nuvo-3616VR series supports up to 2048 x 1536 resolution. By BIOS default and hardware implementation, the VGA output is always enabled in any case. To achieve the best VGA output resolution in Windows, you need to install corresponding graphics driver. Please refer to section 4.5 for information of driver installation.

2.2.8 Remote On/Off Control and Status LED Output



For an application which places Nuvo-3616VR series inside a cabinet, it's useful to control the on/off of the system via an external switch, as well as check how the system's running via some external LED indicators. Nuvo-3616VR series provides a 2x5, 2.0mm pitch wafer connector on the front panel for this purpose.



Pin#	Definition	Description
1	Ctrl+	[Input] Remote on/off control, connecting to an external switch to turn on/off the system (polarity is negligible).
2	Ctrl-	
3	Power+	[Output] System power indicator, on if system is turned on, off if system is turned off.
4	Power-	
5	HDD+	[Output] Hard drive indicator, flashing when SATA hard drive is active.
6	HDD-	
7	IGN+	[Output] Ignition signal indicator, on when ignition signal is supplied.
8	IGN-	
9	WDT+	[Output] Watchdog timer indicator, flashing when watchdog timer is started.
10	WDT-	

Note

Please make sure the polarity is correct when you connect the external LED indicator to the Status LED Output.

Pin#1 and pin#2 are used to turn on or turn off the system remotely by connecting to an external switch. Users should connect a non-latched switch to Ctrl+/Ctrl- as it acts exactly the same as the power button on the front panel. For detail information of using remote on/off control function, please refer to section 3.7.2.

Pin#3 to pin#10 are used to output the system status including power, HDD, ignition signal and watchdog timer status. The status LED output has a built-in series-resistor and provides 3.3V, 10mA current, which means you can use these pins to directly drive external LED indicators.

2.2.9 USB 3.0 Connectors



Nuvo-3616VR series offers two USB 3.0 (SuperSpeed USB) ports on its front Interface. By BIOS default, these USB ports are operated in xHCI (eXtensible Host Controller Interface) mode and are compatible with USB 3.0, USB 2.0, USB 1.1 and USB 1.0 devices. Legacy USB support is also provided so you can use USB keyboard/mouse in DOS environment. To use USB 3.0 ports in Windows 7, you need to install USB 3.0 driver. Please refer to section 4.5 for information of driver installation.

Note

1. Intel USB 3.0 driver does not support Windows XP. In Windows XP, all USB 3.0 ports will work in USB 2.0 mode.

2.2.10 DVI/HDMI Connectors



Nuvo-3616VR series has multiple display outputs on its front panel for connecting different displays according to your system configuration. DVI/HDMI transmits graphics data in

digital format and therefore can deliver better image quality at high resolution. Two DVI/HDMI connectors on the front panel can either output DVI signals or HDMI signal depending on the display device connected. They support up to 1920x1200 resolution. You shall need a DVI to HDMI cable when connecting to a HDMI display device.



To achieve best DVI/HDMI output resolution in Windows, you need to install corresponding graphics driver. Please refer to section 4.5 for information of driver installation.

2.2.11 USB 2.0 Connectors



In addition to two USB 3.0 ports, Nuvo-3616VR series provides another two USB 2.0 ports on the front panel. By BIOS default, these USB 2.0 ports are operated in EHCI (Enhanced Host Control Interface) mode and are compatible with USB 2.0, USB 1.1 and USB 1.0 devices. Legacy USB support is provided so you can use USB keyboard/mouse in DOS environment.

2.2.12 Speaker-out and MIC-in Audio Jacks



Nuvo-3616VR series provides audio function using Intel® High Definition Audio (built-in in QM77 PCH) and Realtek ALC262 Codec. There are two audio jacks on the front panel. The pink one is used for microphone input, and the green one is used for speaker output. To utilize the audio function in Windows, you need to install corresponding drivers for both Intel® QM77 PCH chipset and Realtek ALC262 Codec. Please refer to section 4.5 for information about driver installation.

2.3 Back Panel I/O Functions

To fit more general application requirements, Nuvo-3616VR series offers more I/O functions on its back panel. In this section, we'll illustrate each I/O function on the back panel.

2.3.1 3-Pin Terminal Block for DC Input



Nuvo-3616VR Terminal Block



Nuvo-3608VR Terminal Block

Nuvo-3616VR series allows a wide range of DC power input from 8 to 35V via a 3-pin pluggable terminal block. It is fit for field usage where DC power is usually provided and its screw clamping connection of terminal block gives a very reliable way of wiring the DC power. For detail information of supplying DC power via pluggable terminal block, please refer to section 3.6.

In addition to DC power input, this terminal block is also used for accepting ignition signal input for in-vehicle applications. For detail information of ignition power control, please refer to section 3.8

Pin	Description
V+	Positive polarity of DC power input (8 ~ 35 VDC).
GND	Ground of DC power input.
IGN	Ignition signal input (e.g. ACC power of vehicle).

Caution

1. Please make sure the voltage of DC power is correct before you connect it to Nuvo-3616VR. Supplying a voltage over 35V will damage the system.
2. The IGN input accepts ACC power of car (12VDC) or bus/truck (24VDC). Supply a voltage over 35V to IGN input will damage the system.

2.3.2 COM Ports (COM1 & COM2)




Nuvo-3616VR COM ports



Nuvo-3608VR COM ports

Nuvo-3616VR series provides two COM ports for communicating with external devices. COM1 and COM2 are located on the back panel via 9-pin D-Sub male connectors. They are implemented using industrial-grade ITE8783 Super IO chip (-40 to 85°C) and provide up to 115200 bps baud rate.

Both COM1 and COM2 support software-selectable RS-232/422/485 mode. The operation mode of COM1/COM2 can be set in BIOS setup utility (refer to section 4.1.1 for detail). The following table describes the pin definition of COM ports.



Pin#	RS-232 Mode	RS-422 Mode	RS-485 Mode (Two-wire 485)
1	DCD		
2	RX	422 TXD+	485 TXD+/RXD+
3	TX	422 RXD+	
4	DTR	422 RXD-	
5	GND	GND	GND
6	DSR		
7	RTS		
8	CTS	422 TXD-	485 TXD-/RXD-
9	RI		

2.3.3 Gigabit Ethernet PoE+ Ports



Nuvo-3616VR PoE+ ports



Nuvo-3608VR PoE+ ports

PoE, or Power over Ethernet, is a technology to supply electrical power along with data over a standard CAT-5/CAT-6 Ethernet cable. Nuvo-3616VR series, acting as a PoE+ PSE (Power Sourcing Equipment), integrates PoE+ ports in compliant with IEEE 802.3at standard. Each PoE+ port can deliver up to 25.5 W (160W total budget for Nuvo-3616VR and 80W total budget for Nuvo-3608VR) of power to a PoE+ PD (Powered Device), such as a PoE IP camera. PoE defines a mechanism to automatically detect the device connected and determine whether to dispatch power. This makes PoE port 100% compatible with traditional Ethernet devices.


Nuvo-3616VR offers 16 GigE PoE+ ports and Nuvo-3608VR offers 8 GigE PoE+ ports. These ports are implemented in a controller-switch topology. Every four ports (P1~P4, P5~P8, P9~P12, P13~P16) share the bandwidth of one Intel® I210 controllers via a 1-to-4 GigE switch chip. When only one of four PoE+ ports is occupied, a maximal of 1000 MB/s bandwidth is achievable. When all four ports are connected, all devices share 1000 MB/s bandwidth (i.e. 250 MB/s if all four devices run simultaneously).

When plugging in the Ethernet cable, you can tell the Ethernet status and speed from the LED indicators on the RJ45 connector as following:

Active/Link LED

LED Color	Status	Description
Orange	Off	Link speed is 10 Mbps
	On	Link speed is 100/1000 Mbps
	Flashing	Ethernet port is connected and data is transmitting/receiving

In addition, Nuvo-3616VR series features a unique per-port PoE power on/off control function. Via Neousys' provided API, users can program whether to deliver power to each PoE+ port. This can be useful for some fault-recovery or device power reset actions. Please refer to Appendix B for information of using per-port power on/off control function.




(Sample Program of Per-port On/Off Control)


2.4 Internal I/O Functions

In addition to I/O connectors on the front/back panel, Nuvo-3616VR series provides other useful features via internal connectors, such as SATA ports, mini-PCIe sockets, optional COM ports and etc. In this section, we'll illustrate these internal I/O functions.

2.4.1 DDR3 SODIMM Sockets




Nuvo-3616VR DDR3 SODIMM Sockets




Nuvo-3608VR DDR3 SODIMM Sockets

Nuvo-3616VR series provides two 204-pin, SODIMM sockets for installing DDR3 memory modules. It supports a maximal 16GB capacity by installing two 8GB DDR3 1600MHz SODIMM modules. For information of installing DDR3 memory modules, please refer to section 3.2 for detail.

2.4.2 SATA Ports for Internal HDD



Nuvo-3616VR SATA#1 and SATA#2 Ports




Nuvo-3608VR SATA#1 and SATA#2 Ports


Nuvo-3616VR series provides four SATA ports to accommodate 2.5" SATA drives. Two ports are designed to connect internally-fixed HDD/SSD while the other two ports are designed to connect to easy-swap HDD trays so you can replace the SATA drives without opening the chassis.

These SATA ports are located on a mezzanine board via four 22-pin SATA connectors. SATA#1 and SATA#2 are used in conjunction with the internal HDD bracket to accommodate two 2.5" HDD/SSD. For information of installing a HDD/SSD to SATA#1 and SATA#2 ports, please refer to section 3.3 for detail.

2.4.4 Mini PCI Express Connector#1 (with SIM Socket)



Nuvo-3616VR Mini-PCle Connector#1




Nuvo-3608VR Mini-PCle Connector#1


Nuvo-3616VR series provides two on-board Mini PCI Express connectors. There are plenty of off-the-shelf mini-PCle modules with versatile capabilities. By installing a mini-PCle module, your system can have expanded features such as WIFI, 3G, GPS, RAID and etc. Mini PCI Express Connector#1 is designed with SIM card support. With a SIM card installed, it's capable to connect your system to Internet in wide territory through telecom operator's GPRS/3G/4G network. For WIFI/3G/4G communication, Nuvo-3616VR series provides multiple SMA antenna apertures on the front and back panel for multi-antenna configuration.



2.4.5 Mini PCI Express Connector#2



Nuvo-3616VR Mini-PCle Connector#2




Nuvo-3608VR Mini-PCle Connector#2

Nuvo-3616VR series provides two on-board Mini PCI Express connectors. There are plenty of off-the-shelf mini-PCle modules with versatile capabilities. By installing a mini-PCle module, your system can have expanded features such as WIFI, 3G, GPS, RAID and etc. Mini PCI Express Connector#2 is designed to accommodate full-size or half-size mini PCI-E module. You can install versatile modules, such as WIFI, GPS, RAID controller, mini PCI-E DOM and etc. For communication modules which need external antenna connection, Nuvo-3616VR series provides multiple SMA antenna apertures on the front and back panel for multi-antenna configuration.




2.5 Mechanical Dimension


2.5.1 Top View of Nuvo-3616VR series




2.5.2 Front View of Nuvo-3616VR series



2.5.3 Side View of Nuvo-3616VR series



2.5.4 Bottom View of Nuvo-3616VR series



Chapter 3 Getting Start

In this chapter, we'll illustrate how to disassemble your Nuvo-3616VR series and install peripheral devices. Please follow the correct procedures to prevent any damage on your Nuvo-3616VR series.

3.1 Disassemble your Nuvo-3616VR series


1. Put the Nuvo-3616VR series on a flat surface. Unscrew the hand screws of easy-swap HDD trays and remove the trays from Nuvo-3616VR.



2. Use hex wrench to unscrew the hex socket cap screws on the front and back panel.




3. Remove the front panel, back panel and bottom cover to expose the PCBA with HDD bracket of Nuvo-3616VR.



- Unscrew four M3 F-head screw on SATA HDD bracket and then remove it.



- Unscrew two M3 P-head screws and then remove the mezzanine board.



Note:

- The difference of mechanical parts between Nuvo-3616VR and Nuvo-3608VR is only back panel due to the number of PoE+ ports. The same assembly and peripheral installation procedures can be applied to both Nuvo-3616VR and Nuvo-3608VR.*

3.2 Install DDR3 SODIMM Modules

Nuvo-3616VR series provides two 204-pin, SODIMM sockets for installing DDR3 memory modules. It supports maximal 16GB capacity by installing two 8GB DDR3 1600MHz SODIMM modules. You can install/replace DDR3 SODIMM modules by following the steps listed below.


- Follow step 1~5 in section 3.1 to disassemble the Nuvo-3616VR chassis, and then you can see two SODIMM sockets exposed.

2. Tile the SODIMM module and insert it to the SODIMM socket. As it's firmly contacted with socket connectors, press it down until the clamps of the socket snap into the latching position of SODIMM module. Repeat this step if you want to install the second DDR3 SODIMM module.



3.3 Install 2.5" HDD/SSD on Internal SATA Ports

1. Follow step 1~3 in section 3.1 to remove the bottom cover of the Nuvo-3616VR chassis, and then you can see the internal bracket for 2.5" HDD/SSD drives. Please note the position marked below is the SATA ports for the internal SATA HDD/SSD installation.




2. Put the Nuvo-3616VR on a flat surface and make the side of internal SATA ports toward you so you can see the SATA ports.



3. Gently slide the HDD/SSD drive into the Nuvo-3616VR internal HDD bracket till it's firmly connected to SATA connector.



- Put the Nuvo-3616VR upside down on a flat surface and then fasten four M3 F-head screws to fix the HDD/SSD drive.



3.4 Install 2.5" HDD/SSD on Easy-Swap Trays

SATA#3 and SATA#4 ports of Nuvo-3616VR series are used in conjunction with easy-swap HDD trays to accommodate 2.5" HDD/SSD drives. You can install/replace the HDD/SSD drive to SATA#3 or SATA#4 port by following the steps listed below.

Caution


- Due to electrical/mechanical limitation, SATA#3 and SATA#4 ports are not hot-pluggable. Removing/inserting easy-swap trays when system is running can cause inrush current and damage the system or HDD/SDD drive. Please always access the easy-swap HDD trays when system is powered off.*
- Loose the hand screw and pull out the easy-swap HDD tray.



- Place the HDD/SSD drive on the easy-swap HDD tray. Use a Phillips screwdriver to fix it with four M3 F-head screws. Please note that the HDD/SSD drive must be placed in the right direction as below.



3. Gently slide the HDD tray assembly into the slot on the side of Nuvo-3616VR till it's firmly connected to SATA connector.




4. Fasten the hand screw of the easy-swap HDD tray.



3.5 Install Mini-PCle Module

Nuvo-3616VR series provides two mini-PCle connectors to accommodate versatile mini-PCle modules (e.g. 3G/4G/WIFI/GPS) for further function expansion. In this section, we demonstrate how to install a mini-PCle WIFI module and attach an antenna to your Nuvo-3616VR. Please note that the mini-PCle WIFI module, cable and antenna are not part of Nuvo-3616VR series and may be different according to your system configuration.

1. Follow step 1~4 in section 3.1 to disassemble the Nuvo-3616VR chassis, and then you can see the two mini-PCle connectors exposed. (one with SIM socket)



2. Tilt the mini-PCIe WIFI module and insert it to the mini-PCIe connector. And fix the WIFI module with two M2.5 P-head screws.



3. Attach the IPEX-to-SMA cable to the WIFI module and fix the SMA connector (on the IPEX-to-SMA cable) to the SMA antenna aperture on the back or front panel.



4. Carefully put back the front panel, back panel and bottom cover.



- Fix the hex socket cap screws on the front and back panel.




- Attach the WIFI antenna to the SMA connector.




3.5 Mount your Nuvo-3616VR

Nuvo-3616VR series is shipped with wall-mount brackets as the standard mounting option. You can mount your Nuvo-3616VR series on the wall or on a flat surface by following the steps listed below.



- Get two wall-mounting brackets and four M4 screws from the accessory box. Fix the mounting brackets to Nuvo-3616VR series using M4 screws.



- Place Nuvo-3616VR series on the wall or on a flat surface and fix it with screws. You can also take advantage of the keyhole-shaped holes of mounting brackets to suspend Nuvo-3616VR series on the Wall.




3. For best efficiency of heat dissipation, please mount Nuvo-3616VR series in a right direction when it's vertically mounted on the wall.



3.6 Connect DC Power to you Nuvo-3616VR

Nuvo-3616VR series uses a 3-pin pluggable terminal block to accept 8~35V DC power input. It provides the way for directly wiring the DC power. To connect DC power via the 3-pin pluggable terminal block, please follow the steps listed below.

1. Make sure the external DC power supply is power off or disconnected before wiring.
2. Get the 3-pin pluggable terminal block from the accessory box. The terminal block fits the wires with a gauge of 12~24 AWG.
3. Carefully identify the positive and negative contacts of your DC power supply and pluggable terminal block. The polarities between DC power supply and terminal block must be positive (+) to positive (+) and ground (GND) to ground (GND). For in-vehicle deployment, you can take advantage of the ignition control function by wiring ACC signal to IGN input. Insert the wires and tighten clamping screws using a Phillips screwdriver.



4. Firmly plug the terminal block into a receptacle on the rear panel, and tighten the captive screws using a Slotted screwdriver.



* Neusys provides the option of 280W AC/DC (24V/11.67A) adapter for powering both Nuvo-3616VR/3608VR system and external PoE devices.



Caution

1. *Nuvo-3616VR series accepts 8~35 VDC for DC input. Please make sure the voltage of DC power is correct before you connect it to Nuvo-3616VR series. Supplying a voltage over 35V will damage the system.*

3.7 Power on your Nuvo-3616VR series

For better flexibility of operation, Nuvo-3616VR series provides three alternatives to power on your Nuvo-3616VR series. You can turn on your Nuvo-3616VR series by pressing the power button, using an external non-latched on/off switch, or by sending a special LAN packet. In this section, we illustrate these ways to power on your Nuvo-3616VR series.

3.7.1 Power on Nuvo-3616VR Using the Power Button



This is the simplest way to turn on your Nuvo-3616VR series. The power button on the front panel is a non-latched switch and behaves the ATX-mode on/off control. As DC power is connected, push the power button will turn on the system as well as the PWR LED indicator. Push the button when system is on will turn off the system. If your operating system supports ATX power mode (i.e. Microsoft Windows or Linux), push the power button causes a pre-defined system behavior, such as shutdown or hibernation.



3.7.2 Power on Nuvo-3616VR Using an External Non-latched Switch

For an application which places Nuvo-3616VR series inside a cabinet, it's useful to control the on/off of the system using an external switch. Nuvo-3616VR series provides a 2x5, 2.0mm pitch wafer connector (for detail, please refer to section 2.2.8) for connecting a non-latched switch and behaves ATX-mode power on/off control. The external non-latched switch acts exactly the same as the power button on the front panel. To power on Nuvo-3616VR series using an external non-latched switch (ATX-mode), please follow the steps listed below.

1. Prepare a non-latched switch with a 2x5, 2.0mm pitch wafer terminal. Note that the switch must be connected to pin#1 and pin#2 (polarity is negligible).



2. Connect the wafer terminal to the wafer connector on the front panel of Nuvo-3616VR series.



3. Push the non-latched switch will turn on the system (the PWR LED indicator on the front panel is on at the same time). Push the non-latched switch when system is on will turn off the system. If your operating system supports ATX power mode (i.e. Microsoft Windows or Linux), push the power button causes a pre-defined system behavior, such as shutdown or hibernation.

3.7.3 Power on Nuvo-3616VR Using Wake-on-LAN Function

Wake-on-LAN (WOL) is a mechanism to wake up a computer system from a S5 (system off with standby power) state via issuing a magic packet. Nuvo-3616VR Series implements the Wake-on-LAN function for its first GbE port.




To enable WOL function and power on you Nuvo-3616VR series, please follow the steps listed below.

For Windows XP


1. When Nuvo-3616VR series boots up, press F2 to enter BIOS setup utility.
2. Enter the **[Power]** menu. And configure the **[Wake On LAN]** option as **[Enabled]**.

This setting enables the Wake-on-LAN function for Nuvo-3616VR series. Please refer to section 4.1.5 for the instruction of configuring this BIOS option.

3. In Windows XP system, identify the Local Area Connection of corresponding Intel® 82579LM Gigabit Controller and click the **Configure** button.



Click the Power Management tag, and configure the following two options accordingly.



- **Wake on Magic Packet**

Nuvo-3616VR and Nuvo-3608VR can wake from S5 state when receiving a magic packet. The magic packet is a broadcast frame containing anywhere within its

payload 6 bytes of all 255 (FF FF FF FF FF FF in hexadecimal), followed by sixteen repetitions of the target computer's 48-bit MAC address.

For example, NIC's 48-bit MAC Address is 78h D0h 04h 0Ah 0Bh 0Ch

```

DESTINATION SOURCE MISC
FF FF FF FF FF FF
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C 78 D0 04 0A 0B 0C
MISC    CRC

```


There are some free tools available on Internet that can be used to send a magic packet. Please refer to the following link to understand more about Magic Packet.

<http://en.wikipedia.org/wiki/Wake-on-LAN>


For Windows 7

1. When Nuvo-3616VR series boots up, press F2 to enter BIOS setup utility.
2. Enter the **[Power]** menu. And configure the **[Wake On LAN]** option as **[Enabled]**. This setting enables the Wake-on-LAN function for Nuvo-3616VR series. Please refer to section 4.1.5 for the instruction of configuring this BIOS option.
3. In Windows 7 system, identify the Local Area Connection of corresponding Intel® 82579LM Gigabit Controller and click the **Configure** button.





4. Click the **Power Management** tag, and check the following two options accordingly




3.8 Ignition Power Control

Nuvo-3616VR implements the feature of ignition power control module for in-vehicle applications. It's a MCU-based implementation that monitors the ignition signal and reacts to turn on/off the system according to pre-defined on/off delay. Its built-in algorithm supports further features such as ultra-low standby power, battery-low protection, system hard-off and etc. In this section, we'll illustrate the principle of ignition power control and operations modes on Nuvo-3616VR.

3.8.1 Principle of Ignition Power Control

The basic concept of ignition power control module is to control the timing correlation between ignition signal and system power status. A typical timing correlation can be described in following diagram.



1. When DC input is supplied to Nuvo-3616VR, MCU starts to periodically detect ignition signal. Note that only MCU is working at this moment and the overall power consumption is less than 2 mW.
2. Ignition signal is active. (Both 12VDC and 24VDC ignition signals are accepted)
3. MCU starts to count a pre-defined power-on delay.
4. Once power-on delay expired, MCU turns on necessary standby power for Nuvo-3616VR series (3.3VSB & 5VSB).
5. A PWRBTN# pulse is then issued to turn on the system (a similar behavior as you press the power button on the front panel).
6. Nuvo-3616VR is booting up and running.
7. After a period of time, the ignition signal is inactive.
8. MCU starts to count a pre-defined power-off delay.
9. Once power-off delay expired, another PWRBTN# pulse is issued to perform a soft-off for the system (ex. a normal shutdown process for Windows system).
10. Nuvo-3616VR is completely shut down.
11. As MCU detects system is off, it turns off the standby power for Nuvo-3616VR, and then operates in low power mode again (< 2mW power consumption).

In addition to the typical timing correlation, the ignition power control module offers some further features to make Nuvo-3616VR series more reliable for in-vehicle applications.

1. Low battery detection

The ignition power control module is capable to continuously monitor the voltage of DC input when system is running. If input voltage is less than 9V (for 12VDC input) or less than 18V (for 24VDC input) for the duration of 60 second, it will shut down the system automatically.

2. Guarded power-on/power-off delay duration

If ignition signal goes inactive during the power-on delay duration, the ignition power control module will cancel the power-on delay process and go back to idle status.

Likewise if ignition signal goes active during the power-off delay duration, the ignition power control module will cancel the power-off delay process and keep the system running.

3. System hard-off

In some cases, system may be failed to normally shutdown via a soft-off operation due to system/application halts. The ignition power control module on Nuvo-3616VR series offers a mechanism called "hard-off" to handle this unexpected condition. By detecting the system status, it can determine whether the system is normally shutdown. If not, the ignition power control module will compulsively cut off the system power 10 minutes after the power-off delay duration.

4. Smart off-delay

Mode 6 of ignition power control on Nuvo-3616VR series offers very long power-off delay duration for applications require some off-line processing after vehicle is stopped. In this mode, the ignition power control module will automatically detect the system status during the power-off delay duration. If the system is shutdown (by the application software) in prior to power-off delay expired, it will cut off the system power immediately to prevent further consumption of battery power.



3.8.2 Wiring Ignition Signal



To have ignition power control for in-vehicle usage, you need to supply IGN signal to Nuvo-3616VR series. The IGN input is located on the back panel via a 3-pin pluggable terminal block (shared with DC power input). Here is a general wiring configuration for in-vehicle deployment.


1. Connect car Battery+ line (12V for sedan, 24V for bus/truck) to V+.
2. Connect car Batter-/GND line to GND.
3. Connect ACC line to IGN.

Note

1. Please make sure your DC power source and IGN signal share the same ground.
2. IGN input of Nuvo-3616VR series accepts max. 35VDC. Supply a voltage higher than 35VDC may damage the system.

3.8.3 Operation Modes of Ignition Power Control

Nuvo-3616VR series features ignition power control with configurable power-on/power-off delay via an on-board rotary switch. When the rotary switch is set to mode 0 ~ 6, the ignition control module operates according to pre-defined on/off delay combination. When it's set to mode 7, ignition power control is executed according to parameters configured in BIOS setup menu, which allows richer combination of power-on/power-off delay and more detailed control parameters.



1. Mode 0

Mode 0 is the ATX mode without power-on and power-off delay. User can only use the power button on the front panel to turn on or turn off the Nuvo-3616VR system.

Mode	Power-on Delay	Power-off Delay	Hard-off Timeout
0	N/A	N/A	N/A

2. Mode 1

If Mode 1 is specified, the system automatically turns on the system when DC power is applied. A retry mechanism is designed to repeat the power-on cycle if the system is failed to boot to OS.

Mode	Power-on Delay	Power-off Delay	Hard-off Timeout
1	N/A	N/A	N/A

3. Mode 2 ~ Mode 5

Mode 2 ~ Mode 5 are ignition power control modes with various power-on delay and power-off delay. Each mode supports a hard-off timeout of 10 minutes.

Mode	Power-on Delay	Power-off Delay	Hard-off Timeout
2	10 seconds	10 seconds	10 minutes
3	30 seconds	1 minute	10 minutes
4	30 seconds	5 minutes	10 minutes
5	30 seconds	30 minutes	10 minutes

4. Mode6

Mode 6 is the ignition power control mode with very long power-off delay. This mode supports the feature of “smart off-delay”, which automatically detect system status during power-off delay duration and cut off system power if system is off in prior to power-off delay expired.


Mode	Power-on Delay	Power-off Delay	Hard-off Timeout
6	30 seconds	2 hours	10 minutes

● Mode 7

Nuvo-3616VR supports BIOS-configurable ignition parameters. When the rotary switch is set to 7, users can configurable parameters in BIOS setup menu.

To configure ignition parameters in BIOS, please follow the steps below.

1. Make sure you have set the rotary switch to position 7.
2. When system boots up, press F2 to enter BIOS setup menu.
3. Go to **[Power]** → **[Ignition Power Control]**.



4. You can configure the following parameters for ignition power control according to your application.

[IGN Operation Mode]

ATX	ATX mode without power-on and power-off delay. Same operation as rotary switch set to 0.
AUTO-ON	Automatically turns on the system when DC power is applied. Same operation as rotary switch set to 1.
IGN	Ignition power control mode. Ignition control is executed according to the specified parameters.

[Smart Off-Delay]

Enabled	If system is manually shutdown during the power-off delay period, ignition control module will cut off system power in prior to expiration of power-off delay to save battery power.
Disabled	Ignition control module cut off system power only after power-off delay expired.

[BIOS POST Check]

Enabled	This option secures a boot-to-OS operation. If the system is failed to boot to OS (e.g. disk failure or no bootable device) within 60 seconds, ignition control module will cut off system power and retry another power on cycle.
Disabled	BIOS POST check is skipped.

[Power On Delay]

Specify the power-on delay duration. Once IGN signal goes active and sustains for the duration of power-on delay, ignition control module turns on system power and boot up the system.

[Power Off Delay]

Specify the power-off delay duration. Once IGN signal goes inactive and sustains for the duration of power-off delay, ignition control module performs system shutdown (soft-off) and then cut off system power.

[Hard-off Timeout]

Specify system hard-off timeout. Once system failed to normally shutdown via a soft-off operation due to system/application halts (e.g. Windows BSOD), ignition control module can compulsively cut off system power after the given hard-off timeout.



[Battery Voltage]

Specify the battery voltage of the vehicle where Nuvo-3616VR is deployed. Typically it's 12 VDC for sedan and 24 VDC for bus/truck.

[Low Battery Threshold]

When system is running, ignition control module continuously monitors the battery voltage. Once the battery voltage is lower than the specified threshold, it performs system shutdown (soft-off) and cut off system power to prevent battery drain-out. You should specify the low battery threshold according to the given battery voltage.

5. Press F10 to save configured parameters. The ignition control module will be reset and then operate according to parameters configured in BIOS setup menu.

Chapter 4 BIOS and Driver

4.1 BIOS Settings


Nuvo-3616VR series is shipped with factory-default BIOS settings cautiously programmed for best performance and compatibility. In this section, we'll illustrate some of BIOS settings you may need to modify. Please always make sure you understand the effect of change before you proceed with any modification.

4.1.1 COM1 & COM2 Operating Mode

COM1 and COM2 of Nuvo-3616VR series support RS-232 (full-duplex), RS-422 (full-duplex) and RS-485 (half-duplex) mode. You can set the COM1/COM2 operating mode via BIOS settings. Another option in BIOS called "*Slew Rate*" defines how sharp the rising/falling edge is for the output signal of COM1/COM2. For long-distance RS-422/485 transmission, you may set the "*Slew Rate*" option as "High" to improve signal quality.

To set COM1/COM2 operating mode:

1. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
2. Go to **[Advanced]** → **[Peripheral Configuration]**.
3. Set the **[Set COM1 as]** to a proper mode for COM1 of your Nuvo-3616VR series.
4. Set the **[Set COM2 as]** to a proper mode for COM2 of your Nuvo-3616VR series.



4.1.2 SATA Controller Mode


The SATA controller of Nuvo-3616VR series supports three operating modes: **IDE**, **AHCI** and **RAID** mode. **IDE** mode configures SATA controller to access SATA interface in legacy IDE mode, and is compatible with most storage devices. **AHCI** mode, which exposes SATA's advanced capabilities such as hot swapping and native command queuing, is supported in several later version of operating systems. **RAID** mode provides a more reliable data storage (RAID 1/5/10) or a higher disk access throughput (RAID 0/5/10). Nuvo-3616VR series features built-in hardware RAID. No additional H/W or driver is needed to use RAID function.

Our suggestion of how to set SATA controller mode is

- If you're using Windows XP, Linux kernel earlier than 2.6.19, you should select **IDE** mode.
- If you're using Windows Vista, Windows 7, Windows 8, or Linux kernel from 2.6.19 onward, you can select **AHCI** mode for better performance.
- If you're installing more two 2.5" HDD/SSD and looking for data redundancy or higher disk throughput, you can select **RAID** mode to utilize built-in RAID.

To set SATA controller mode:

1. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
2. Go to **[Advanced]** → **[IDE Configuration]**.
3. Set the **[HDC Configure as]** to a proper mode for your Nuvo-3616VR.




4.1.3 Power On after Power Failure Option

This option defines the behavior of Nuvo-3616VR series when DC power is supplied.

Value	Description
S0 – Power On	System is powered on when DC power is supplied.
S5 – Power Off	System is kept in off state when DC power is supplied.
Last State	The on/off state of the system is determined according to the last state when DC power is disconnected. For example, if system is still on but DC power is unplugged, the system is powered on next time when DC power is supplied.

To set “Power On after Power Failure” option:

1. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
2. Go to **[Advanced]** → **[Chipset Configuration]**.
3. Set the **[Power On after Power Failure]** to a proper value for your Nuvo-3616VR series.



4.1.4 W_DISABLE# for Mini-PCle Sockets


Nuvo-3616VR series feature two mini-PCle sockets for function expansion. According to PCI Express Mini Card Specification Rev. 2.0, two signals, W_DISABLE1# and W_DISABLE2#, are defined to enable/disable radio operation of add-on modules. The BIOS of Nuvo-3616VR series provides user-configurable options to control the W_DISABLE# signals for each mini-PCle socket. Please note that most off-the-shelf mini-PCle modules support PCI Express Mini Card Specification Rev. 1.2 only and



therefore we suggest to set **[W_DISABLE1#]** as [High] and **[W_DISABLE2#]** as [Low] to minimize compatibility issue

To configure W_DISABLE# for each mini-PCIe socket:

1. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
2. Go to **[Advanced]** → **[Mini-PCIe Configuration]**.
3. Set the **[W_DISABLE1#]** and **[W_DISABLE2#]** to a proper value according to your application.




4.1.5 Wake-on-LAN Option

Wake-on-LAN (WOL) is a mechanism which allows you to turn on your Nuvo-3616VR series via Ethernet connection. To utilize Wake-on-LAN function, you have to enable this option first in BIOS settings. Please refer to section 3.7.3 for instructions of using WOL function.

To enable/disable “Wake on LAN” option:

1. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
2. Go to **[Power]**.
3. Enable/disable the **[Wake on LAN]** option according to your application.



4.1.6 Watchdog Timer for Booting

The BIOS of Nuvo-3616VR series has a useful feature which allows users to use the watchdog timer to secure the booting process. You can specify the timeout value for watchdog timer. Once the watchdog timer expires, the BIOS issues a reset command to initiate another booting process. You can also set the behavior of how to stop the watchdog timer. There are two options in BIOS menu, “*Automatically after POST*” and “*Manually after Entering OS*”. When “*Automatically after POST*” is selected, the BIOS automatically stop the watchdog timer after POST (Power-On Self Test) OK. When “*Manually after Entering OS*” is selected, it’s user’s responsibility to stop the watchdog timer when entering OS. This guarantees the system can always boot to OS, otherwise another booting process will be initiated. For information about programming watchdog timer, please refer to **Appendix A Using Watchdog Timer**.

To set the watchdog timer for boot in BIOS:

5. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
6. Go to **[Boot]** menu.
7. Disable or select timeout value for **[WDT for Booting]** option.
8. Once you give a timeout value, the **[WDT Stop Option]** option appears. You can select “*Automatically after POST*” or “*Manually after Entering OS*”.




4.1.7 Select a Boot Device

When you have multiple bootable devices connected to your Nuvo-3616VR (e.g. HDD, mSATA, USB flash disk, USB DVD-drive), you may need to select one of them as the boot device. There are two ways to select the device. You can either, press F12 when system boots up to go to Boot Manager and then select one of the devices, or select the boot device in BIOS settings.

To select a boot device in BIOS:


1. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
2. Go to **[Boot] → [Boot Device]**.
3. The **[Boot Menu Type]** option decides whether to list all bootable devices connected to your Nuvo-3616VR according to **[By Device]** or **[By Device Type]**. You can use F5/F6 or +/- to change the boot order of devices or device categories.



4.1.8 Position New Boot Device

When you plug a newly-installed boot device (e.g. USB flash disk, CFast and etc.), this option allow you determine whether to place the new boot device in the first place or the last place in the boot sequence.

1. When Nuvo-3616VR boots up, press F2 to enter BIOS setup utility.
2. Go to **[Boot]** menu.
3. The **[Add New Boot Device]** option decides whether to place the newly-installed boot device to the **First** place or the **Last** place in the boot sequence.




4.2 Configure AMT

Intel® AMT (Active Management Technology) is a hardware-based technology for remotely managing target PCs via Ethernet connection. Nuvo-3616VR series supports AMT function via its first Ethernet port. In prior to use AMT to remotely control Nuvo-3616VR series, you need to configure AMT password and network settings.

1. Make sure you have Ethernet connection on the first Ethernet port of Nuvo-3616VR series.



2. Press F10 when Nuvo-3616VR series boots up. A MEBx configuration page appears.



3. Select "MEBx Login" and you're asked for password. The default password is "admin".
4. For further AMT configuration, please refer to Intel® MEBX User Guide for Intel® 7 Series Chipset. You can find related information at <http://www.intel.com/support/motherboards/desktop/sb/CS-033768.htm>

4.3 Configure RAID Function

Nuvo-3616VR series supports hardware RAID function for more reliable and efficient disk access. The built-in RAID supports RAID 0 (data striping), RAID 1 (data mirroring), RAID 5 (data striping + parity) and RAID 10 (data striping + mirroring). You can configure RAID mode according to your application by following steps listed below.

1. Make sure you've configured SATA controller to **RAID** mode (refer to section 4.1.2 for further information).
2. Reboot Nuvo-3616VR, you will see a UI banner for RAID configuration.

```

Intel(R) Rapid Storage Technology - Option ROM - 11.6.0.1702
Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.

RAID Volumes:
None defined.

Physical Devices:
ID   Device Model      Serial #           Size Type/Status(Vol ID)
0    ST9320328CS      6VDE03HW          298.0GB Non-RAID Disk
1    ST9320328CS      5VD35HKF          298.0GB Non-RAID Disk
2    ST9320328CS      6VDDYKG2          298.0GB Non-RAID Disk
3    ST9320328CS      6VD9QA5T          298.0GB Non-RAID Disk
4    16GB SATA Flash  2011111000000003  14.9GB Non-RAID Disk
Press <CTRL-I> to enter Configuration Utility....

```

3. Press CTRL-I to enter RAID configuration screen. You can create, delete or configure your RAID volume here.

```

Intel(R) Rapid Storage Technology - Option ROM - 11.6.0.1702
Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.

[ MAIN MENU ]
1. Create RAID Volume      4. Recovery Volume Options
2. Delete RAID Volume     5. Acceleration Options
3. Reset Disks to Non-RAID 6. Exit

[ DISK/VOLUME INFORMATION ]

RAID Volumes:
None defined.

Physical Devices:
ID   Device Model      Serial #           Size Type/Status(Vol ID)
0    ST9320328CS      6VDE03HW          298.0GB Non-RAID Disk
1    ST9320328CS      5VD35HKF          298.0GB Non-RAID Disk
2    ST9320328CS      6VDDYKG2          298.0GB Non-RAID Disk
3    ST9320328CS      6VD9QA5T          298.0GB Non-RAID Disk
4    16GB SATA Flash  2011111000000003  14.9GB Non-RAID Disk

[↑↓]-Select      [ESC]-Exit      [ENTER]-Select Menu

```

4.4 Operating System Support

Nuvo-3616VR series supports most operating system developed for Intel® x86 architecture. The following list contains the operating systems which have been tested in Neosys Technology Inc.

- Microsoft Window XP 32-bit
- Microsoft Window 7 32-bit
- Microsoft Window 7 64-bit
- Microsoft Window 8 32-bit
- Microsoft Window 8 64-bit
- Ubuntu 11.04 Desktop or later revision*
- Ubuntu 10.10 Desktop or later revision)*
- Debian 6.0 or later revision *
- Fedora 14 or later revision *
- CentOS 6.4 or later revision

**For Linux system, user may need to manually compile and install the driver for Intel 82579LM/I210 GbE controller if the driver is not embedded in kernel. You can visit Intel website for further information.*

Neosys will keep this list updated as we continuously test other operating systems with Nuvo-3616VR series. Please contact us for the latest OS support list.



4.5 Driver Installation

Neosys Technology Inc. provides a very convenient utility in “Drivers & Utilities DVD” to allow the “One-Click” driver installation. This utility automatically detects your Windows operating system and installs all necessary drivers to your Nuvo-3616VR series with just one mouse click.

4.5.1 Install All Drivers Using “One-Click” Driver Installation

1. Insert the “Drivers & Utilities DVD” into a USB DVD-drive attached to your Nuvo-3616VR series. A setup utility launches and the following dialog appears.



2. Click on the “**Automatic Driver Installation**”. The setup utility will automatically detect your Windows operating system and install all necessary drivers. According to different versions of Windows, the installation process takes about 6~8 minutes. Once driver installation is done, the setup utility reboots your Windows and your system works normally afterward.

4.5.2 Install Drivers Manually

You can also manually install each driver for Nuvo-3616VR series. Please refer to the following information about installing drivers for different operating system.

Windows XP SP3

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_7_Series\ALL\infinst_autol.exe)
2. .NET Framework 3.5 (x:\Driver_Pool\DotNET35\XP\dotnetfx35.exe)
3. Graphics driver (x:\Driver_Pool\Graphics_3rd_i7_Vlv\XP\Setup.exe)
4. Audio driver (x:\Driver_Pool\Audio_ALC262\XP\Setup.exe)
5. LAN driver (x:\Driver_Pool\GbE_I210\XP\I210_XP_Install.exe)
6. ME driver (x:\Driver_Pool\ME_7_Series\ALL\Setup.exe)

Windows XP SP2

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_7_Series\ALL\infinst_autol.exe)
2. Windows Installer 3.1
(x:\Driver_Pool\DotNET35\XP\WindowsInstaller-KB893803-v2-x86.exe)
3. .NET Framework 3.5 (x:\Driver_Pool\DotNET35\XP\dotnetfx35.exe)
4. Audio patch for HD audio
(x:\Driver_Pool\Audio_ALC262\XP\MSHDQFE\Win2K_XP\us\kb888111xpsp2.exe)
5. Graphics driver (x:\Driver_Pool\Graphics_3rd_i7_Vlv\XP\Setup.exe)
6. Audio driver (x:\Driver_Pool\Audio_ALC262\XP\Setup.exe)
7. LAN driver (x:\Driver_Pool\GbE_I210\XP\I210_XP_Install.exe)
8. ME driver (x:\Driver_Pool\ME_7_Series\ALL\Setup.exe)

Windows 7 32-bit

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_7_Series\Win7_8_ALL\SetupChipset.exe)
2. Graphics driver (x:\Driver_Pool\Graphics_3rd_i7_Vlv\Win7_8_32\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win7_8_ALL\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210\Win7_8_32\APPS\PROSETDX\Win32\DxSetup.exe)
5. USB 3.0 driver (x:\Driver_Pool\USB3_7_Series\Win7_ALL\Setup.exe)
6. ME driver (x:\Driver_Pool\ME_7_Series\Win7_8_AMT\Setup.exe)



Windows 7 64-bit

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_7_Series\Win7_8_ALL\SetupChipset.exe)
2. Graphics driver (x:\Driver_Pool\Graphics_3rd_i7_Vlv\Win7_8_64\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win7_8_ALL\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210\Win7_8_64\APPS\PROSETDX\Winx64\DxSetup.exe)
5. USB 3.0 driver (x:\Driver_Pool\USB3_7_Series\Win7_ALL\Setup.exe)
6. ME driver (x:\Driver_Pool\ME_7_Series\Win7_8_AMT\Setup.exe)

Windows 8 32-bit

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_7_Series\Win7_8_ALL\SetupChipset.exe)
2. Graphics driver (x:\Driver_Pool\Graphics_3rd_i7_Vlv\Win7_8_32\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win7_8_ALL\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210\Win7_8_32\APPS\PROSETDX\Win32\DxSetup.exe)
5. ME driver (x:\Driver_Pool\ME_7_Series\Win7_8_AMT\Setup.exe)

Windows 8 64-bit

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_7_Series\Win7_8_ALL\SetupChipset.exe)
2. Graphics driver (x:\Driver_Pool\Graphics_3rd_i7_Vlv\Win7_8_64\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win7_8_ALL\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210\Win7_8_64\APPS\PROSETDX\Winx64\DxSetup.exe)
5. ME driver (x:\Driver_Pool\ME_7_Series\Win7_8_AMT\Setup.exe)



4.5.3 Install Driver for WDT and Per-port PoE On/Off Control

Neosys provides a driver package which contain function APIs for WDT and per-port PoE power on/off control function. You should install the driver package (WDT_DIO_Setup.exe) in prior to use these functions. Please note that you must install WDT_DIO_Setup_v2.1.0 or later revision for Nuvo-3616VR series.

Windows XP SP3

Please execute the driver setup program in the following directory.

x:\Driver_Pool\WDT_DIO\XP_Win7_32\WDT_DIO_Setup_v2.1.0.exe

Windows 7 32-bit

Please execute the driver setup program in the following directory.

x:\Driver_Pool\WDT_DIO\XP_Win7_32\WDT_DIO_Setup_v2.1.0.exe

Windows 7 64-bit

Please execute the driver setup program in the following directory.

x:\Driver_Pool\WDT_DIO\Win7_64\WDT_DIO_Setup_v2.1.0(x64).exe



Appendix A Using Watchdog Timer

Neosys Nuvo-3616VR series provide a watchdog (WDT) timer function to ensure a more reliable system operation. The WDT is a hardware mechanism to reset the system if the watchdog timer is expired. Users can start the WDT and keeping resetting the timer to make sure the system or program is running. Otherwise, the system shall be reset.

In this document, we'll illustrate how to use the function library provided by Neosys to program the WDT functions. Currently, WDT driver library supports the following operating systems:


- Windows XP
- Windows Vista (32-bit)
- Windows 7 (32-bit & 64-bit)

For other OS support, please contact Neosys Technology for further information.

Install WDT_DIO Library

The WDT_DIO function library is delivered in the form of a setup package named **WDT_DIO_Setup.exe**. In prior to program WDT, you should execute the setup program and install the WDT library. Please note that you must use WDT_DIO_Setup_v2.1.0 or later revision for Nuvo-3616VR series.


1. Execute **WDT_DIO_Setup.2.1.0.exe**. The following dialog appears.



2. Click “Next >” and specify the directory of installing related files. The default directory is *C:\Neosys\WDT_DIO*.



3. Once the installation is finished, a dialog appears to prompt you to reboot the system. The WDT & DIO library will take effect after system rebooting.



4. When you programming your WDT or DIO program, the related files are located in
- Header file: \Include
 - Lib file: \Lib
 - Function Reference: \Manual
 - Sample Code: \Sample\WDT_Demo (Demo for Watchdog Timer)
 - \Sample\PoE_Demo (Demo for Per-port PoE Control)

WDT Function Reference

InitWDT

Syntax

```
BOOL InitWDT(void);
```

Description

Initialize the WDT function. You should always invoke InitWDT() before set or start watchdog timer.

Parameter

None

Return Value

Returns TRUE if initialization successes, FALSE if initialization failed.

Usage

```
BOOL bRet = InitWDT();
```

SetWDT

Syntax

```
BOOL SetWDT(WORD tick, BYTE unit);
```

Description

Set timeout value and unit for watchdog timer. When InitWDT() is invoked, a default timeout value of 255 seconds is assigned.

Parameter

tick

WORD value (1 ~ 65535) to indicate timeout ticks.

unit

BYTE value (0 or 1) to indicate unit of timeout ticks.

0 : unit is minute

1: unit is second

Return Value

If value of unit is correct (0 or 1), this function returns TRUE, otherwise FALSE.

Usage

```
WORD tick=255;
```

```
BYTE unit=1; //unit is second.
```

```
BOOL bRet = SetWDT(tick, unit); //timeout value is 255 seconds
```



StartWDT

Syntax

```
BOOL StartWDT(void);
```

Description

Start countdown of WDT. When WDT is started, the WDT LED indicator starts to blink in a frequency of 1Hz. If no ResetWDT() or StopWDT is invoked before WDT is counted to 0, the WDT expires and system resets.

Parameter

None

Return Value

If the timeout value is given in correct format, this function returns TRUE, otherwise FALSE.

Usage

```
BOOL bRet = StartWDT();
```

ResetWDT

Syntax

```
BOOL ResetWDT(void);
```

Description

Reset the timeout value to the value given by SetWDT(). If no ResetWDT() or StopWDT is invoked before WDT is counted to 0, the WDT expires and system resets.

Parameter

None

Return Value

Always returns TRUE;

Usage

```
BOOL bRet = ResetWDT();
```

StopWDT

Syntax

```
BOOL StopWDT(void);
```

Description

Stop the countdown of WDT. When WDT is stopped, the WDT LED indicator stops blinking.

Parameter

None

Return Value



Always returns TRUE;

Usage

BOOL bRet = StopWDT()



Appendix B Using Per-Port PoE On/Off Control

Nuvo-3616VR series supports a unique feature to allow users manually turn on or turn off the power of each PoE port. This can be helpfully for fault-recovery or device power reset purpose.

The function APIs are encapsulated in Neosys WDT_DIO driver package. Please following the instructions in **Appendix A - Install WDT_DIO Library** to install the driver package in prior to program per-port PoE on/off control function.

Per-Port PoE On/Off Control Function Reference

GetStatusPoEPort

Syntax

```
BYTE GetStatusPoEPort (Byte port);
```

Description

Get the current on/off status of designated PoE port.

Parameter

port

BYTE value specifies the index of PoE port. For Nuvo-3616VR series, *port* should be a value of 1 ~ 16. You can see the printed port# on the rear panel of Nuvo-3616VR series.

Return Value

BYTE value indicating PoE on/off status. 0 if port is disabled (off), 1 if port is enabled (on).

Usage

```
BYTE bEnabled = GetStatusPoEPort (1); //Get on/off status of PoE Port#1
```

EnablePoEPort

Syntax

```
BOOL EnablePoEPort (BYTE port);
```

Description

Turn on PoE power of designated PoE port.

Parameter

port

BYTE value specifies the index of PoE port. For Nuvo-3616VR series, *port* should



be a value of 1 ~ 16. You can see the printed port# on the rear panel of Nuvo-3616VR series.

Return Value

Returns TRUE on success, return FALSE if the function failed.

Usage

```
BOOL bRet = EnablePoEPort (1); //Turn on PoE Port#1
```

DisablePoEPort**Syntax**

```
BOOL DisablePoEPort (BYTE port);
```

Description

Turn off PoE power of designated PoE port.

Parameter

port

BYTE value specifies the index of PoE port. For Nuvo-3616VR series, *port* should be a value of 1 ~ 16. You can see the printed port# on the rear panel of Nuvo-3616VR series.

Return Value

Returns TRUE on success, return FALSE if the function failed.

Usage

```
BOOL bRet = DisablePoEPort (1); //Turn off PoE Port#1
```